



This part number complies with RoHS.

Notice: JYEBAO reserves the right to make modifications deemed appropriate.



CABLE ASSEMBLY INSTRUCTION						
SMA33VT-0047	JYE BAO CO., LTD.					
A	В	С	D	E		
COUPLING NUT		TACT PIN	RETAINER RING	GASKET		
DIAGRAM		ASSEMBLY INSTRUCTION				
2.5 [.098]		Step 1: STRIP AS SHOWN .				
	Step 2: PUT 0.4 MM GAGE IN PLACE, INSERT CABLE'S CENTER CONDUCTOR INTO CENTER PIN " C " AND SOLDER IN " Y ".					
ST-047 A ST-011 ST-008		Step 3: INSERT PREPARED CABLE INTO CONNECTOR BODY " A " AND USE SOLDERING FIXTURE " ST-008 " , INSERT TOOL " ST-047 " AND LOCATOR TOOL " ST-011 " TO FIX THE CONNECTOR. SOLDER IN " X ".				
	B D E Z C			Step 4: CLIP RETAINER RING " D " AND GASKET " E " ONTO THE BACK OF CONNECTOR BODY " B " . ADD EPOXY IN " Z " .		
		Step 5: SLIDE BODY " B " INTO THE COUPLING NUT " A ".				
		•				

This part number complies with RoHS. Notice: JYEBAO reserves the right to make modifications deemed appropriate.